

ONE



SIT-STAND DESK SYSTEM ONE OPERATION MANUAL



2 level column:
650-1150 mm

SAFETY AND WARNINGS

Inappropriate use of this product may cause property or bodily injury.

Check surroundings on all sides before using the desk. Do not place any objects taller than 620 mm (2 level columns) under the desk or frame.

Ensure the length of power cords are accounted for when operating the desk. Monitors, computers, speakers, anything with a cord that is not long enough for the desk's range of motion could be pulled down or have its wires broken. Check that no cables can get jammed.

Desks should not be used in environments with high humidity or dampness.

If you need to move the desk, DO NOT lift it only by holding the desktop. Lifting this way can stress the fasteners connecting the frame to the desktop.

Please provide this operation manual to any users, installers, or support personnel operating the product.

USAGE

This sit-stand desk has 2 electric lifting columns.

The desk height is adjustable so the desktop can be fixed for most suitable user's position. These desks are designed only for ergonomic sit-stand position. Do not move around, crawl or lie under the desk frame. Do not sit or stand on the desk frame or desktop. Any other use is at user's risk.

SETUP AND INSTALLATION

Choose a placement for the desk that is a safe distance from window frames, radiators, furniture etc.

Once the desk has been assembled, adjust the feet so that the desk is level and does not shift its position. After this, connect the desk to the outlet and the desk is ready for use. **For the first start of desk please press and hold "down" button for control box activation.**

IMPORTANT

40
KG

**Functional load of desk is 40 kg.
Do not exceed this given load.**

1
MIN

**! Please keep in mind that time for
continuous desk movement upwards or
downwards is 1 minute.**

9
MIN

**After 1 minute of unstopped operation there
has to be a resting period of 9 minutes.**

38
MM/S

Travel Speed Up to 38 mm/s.

TROUBLESHOOTING

- If there is no response when trying to raise or lower the desk you have to make reset of control box: Press "down" and "up" buttons at the same time for about 5 seconds, you will hear short "beep" signal. Now press "down" button, the desk will slowly move down till it stops, you will hear short "beep" signals. The desk adjustment was made, now it should function properly.

- If the desk does not go up: Press the "down" button and lower the desk till there is 100 mm gap to lowest position. Press "down" and "up" buttons at the same time for about 5 seconds, you will hear short "beep" signal. Now press "down" button, the desk will slowly move down till it stops, you will hear short "beep" signals. The desk adjustment was made, now it should function properly.

If these tips were not helpful please contact your seller.

